

ARREL
AUDIO

1

PAN MUTE SOLO LEVEL

3

PAN MUTE SOLO LEVEL

5

PAN MUTE SOLO LEVEL

7

PAN MUTE SOLO LEVEL

9

PAN MUTE SOLO LEVEL

11

PAN MUTE SOLO LEVEL

13

PAN MUTE SOLO LEVEL

15

PAN MUTE SOLO LEVEL

2

PAN MUTE SOLO LEVEL

4

PAN MUTE SOLO LEVEL

6

PAN MUTE SOLO LEVEL

8

PAN MUTE SOLO LEVEL

10

PAN MUTE SOLO LEVEL

12

PAN MUTE SOLO LEVEL

14

PAN MUTE SOLO LEVEL

16

PAN MUTE SOLO LEVEL

CL - 266

LEFT RIGHT

SEND RETURN

INSERT

SOLO MUTE L MUTE R

MONO PHONES

MONITOR SUMMING MIXER