

**ARREL**  
AUDIO

STEPPED CONTROLS MODULE							CONTINUOUS CONTROLS MODULE						
<b>BAND PASS</b> 40 30 25 15 10 Hz	<b>SHELF</b> -2 0 +2 -4 -6 -8 -10 +10 +15 <b>HI</b>	<b>PARAM LO</b> Q 0 0	<b>PARAM MID-LO</b> Q 0 0	<b>PARAM MID</b> Q 0 0	<b>PARAM MID-HI</b> Q 0 0	<b>PARAM HI</b> Q 0 0	<b>BAND PASS</b> 40 30 25 15 10 Hz	<b>SHELF</b> -2 0 +2 -4 -6 -8 -10 +10 +15 <b>HI</b>	<b>PARAM LO</b> Q 0 0	<b>PARAM MID-LO</b> Q 0 0	<b>PARAM MID</b> Q 0 0	<b>PARAM MID-HI</b> Q 0 0	<b>PARAM HI</b> Q 0 0
<input type="radio"/> LO CUT <input type="radio"/> HI CUT	<input type="radio"/> Y	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> LO CUT <input type="radio"/> HI CUT	<input type="radio"/> Y	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB	<input type="radio"/> 7 8 9 10 <input type="radio"/> 6 5 4 dB
<input type="radio"/> dB/2 <input type="radio"/> PEAK OFF PEAK	<input type="radio"/> dB/2 <input type="radio"/> ON	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> dB/2 <input type="radio"/> PEAK OFF PEAK	<input type="radio"/> dB/2 <input type="radio"/> ON	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB	<input type="radio"/> + 3 2 1 <input type="radio"/> 0 F F dB
<b>PARAMETRIC</b>		<b>FREQ TRIM</b>	<b>FREQ TRIM</b>	<b>FREQ TRIM</b>	<b>FREQ TRIM</b>	<b>FREQ TRIM</b>	<b>PARAMETRIC</b>		<b>FREQ TRIM</b>	<b>FREQ TRIM</b>	<b>FREQ TRIM</b>	<b>FREQ TRIM</b>	<b>FREQ TRIM</b>
<input type="radio"/> 0 <input type="radio"/> -6 <input type="radio"/> +6	<input type="radio"/> -2 0 +2 <input type="radio"/> -4 -6 -8 -10 <input type="radio"/> +10 <b>LO</b>	<input type="radio"/> 0 <input type="radio"/> 75 100 <input type="radio"/> 55 40 20 Hz	<input type="radio"/> 0 <input type="radio"/> 300 400 <input type="radio"/> 110 80 80 Hz	<input type="radio"/> 0 <input type="radio"/> 1125 1500 <input type="radio"/> 600 420 300 Hz	<input type="radio"/> 0 <input type="radio"/> 3.75 5 <input type="radio"/> 2 1 1 KHz	<input type="radio"/> 0 <input type="radio"/> 15 20 <input type="radio"/> 11 8 5.6 4 KHz	<input type="radio"/> 0 <input type="radio"/> -6 <input type="radio"/> +6	<input type="radio"/> -2 0 +2 <input type="radio"/> -4 -6 -8 -10 <input type="radio"/> +10 <b>LO</b>	<input type="radio"/> 50 60 <input type="radio"/> 40 30 20 Hz	<input type="radio"/> 160 200 240 <input type="radio"/> 130 100 80 100 Hz	<input type="radio"/> 600 800 <input type="radio"/> 500 400 300 400 Hz	<input type="radio"/> 2.5 3 <input type="radio"/> 2 1.5 1 1.5 KHz	<input type="radio"/> 10 12 <input type="radio"/> 8 6 4 10 KHz
<input type="radio"/> PHASE	<input type="radio"/> Y	<input type="radio"/> 28 20 Hz	<input type="radio"/> 110 80 Hz	<input type="radio"/> 600 420 Hz	<input type="radio"/> 2 1 KHz	<input type="radio"/> 11 8 5.6 4 KHz	<input type="radio"/> PHASE	<input type="radio"/> Y	<input type="radio"/> Hz	<input type="radio"/> Hz	<input type="radio"/> Hz	<input type="radio"/> KHz	<input type="radio"/> KHz
<input type="radio"/> ML-117a	<input type="radio"/> ML-117c	<input type="radio"/> ML-117i	<input type="radio"/> ML-117m	<input type="radio"/> ML-117n	<input type="radio"/> ML-117o	<input type="radio"/> ML-117p	<input type="radio"/> ML-117e	<input type="radio"/> ML-117b	<input type="radio"/> ML-117r	<input type="radio"/> ML-117f	<input type="radio"/> ML-117g	<input type="radio"/> ML-117h	<input type="radio"/> ML-117l

ML - 117  
MONSTER  
EQ

STEPPED CONTROLS MODULE

CONTINUOUS CONTROLS MODULE